

Electric Syrup Measuring Machine



Instruction : [The Control Panel]

1. There are 16 sugar buttons on the right, which can be set according to the amount of sugar needed, ranging from 0 to 250.
2. Press the "continuous/stop" button for 3 seconds and leave it after the "Beep" to release or stop the sugar in standby mode.
3. The "Setting" button can set the amount of sugar and other machine parameters. in standby mode, press the "Setting" button could set the amount of sugar in 16 different groups, and press save and exit after setting. Press the "Setting" button for 5 seconds could set up the machine parameters.

Manual instruction:

1. If suddenly heard "Beep" and the supply light flashing, which indicating that the liquid level is too low to operate. In order to avoid affecting the operation and ensure saccharin accuracy, please supply and add fructose immediately.
2. When the screen shows "Edy", it means that the machine is in heating mode, and the machine could be operated when it shows "YF".
3. Press the "continuous/stop" button for 3 seconds and leave it after the "Beep" to release or stop the sugar.
4. In stand-by mode, press "▲" check the counter. Long press for 3 seconds to reset the machine. Press "store" to check the current temperature.
5. Single flow rate setting: press "setting" button → press the buttons you want to.
Set up → press "▲" or "▼" to revise the syrup flow rate → press other buttons that need to set up to revise → press "store"

after finishing setting or no need to setup, then the setting is done.

6. Everyday when you turn on the syrup dispenser, please make the machine work for 2-3.times after finishing heated,or press the "continue stop"(and then press "continue stop"),then the machine will dispense the inner syrup without heated (about 200cc).to make sure the accuracy of the flow rate, and the dispense inner syrup can be reused.

7. The tap pipe will have air when you start to use the machine. If you press the button of.draining syrup and the machine are noisy but do not drain the syrup, please press the syrup draining button after unscrewing the syrup draining tap, and then press the syrup draining button again, if the syrup is draining, you can screw the syrup draining tap(the top side is the daring tap and rubber plug with 2 holes, the coil spring is a down.) on the machine.

Notes:

1. Please rinse the machine using about 70-degree water when first time using and wipe it clean and add fructose (up to 80%), then press "continuous/stop "button to drain the air and water from the machine.
2. When supplementation of fructose, it should not be too full, not more than 80%, so as to avoid a large number of bubbles produced by the fructose machine, which will affect the accuracy.
3. The machine and tube should be clean up in each week by filling about 70-degree water and then pressing "continuous/stop "button.